

How to switch between your computer and document camera on your projector...

STEP 1: Turn on the projector by pressing



ON/STANDBY

STEP 2: Turn on computer and projector




STEP 3: Press **INPUT**, notice choices on screen
TO DISPLAY THE COMPUTER SCREEN:



STEP 4: Press the **up** button to select **COMPUTER**



STEP 5: Press the **MENU** button to make the selection




OR IF YOU WANT TO DISPLAY THE DOCUMENT CAMERA:

STEP 4: Press the **down** button to select **S-VIDEO**



STEP 5: Press the **MENU** button to make the selection



Follow these steps to toggle back and forth between both as needed.

PLEASE REMEMBER TO PRESS THE INPUT BUTTON ONCE TO PLACE THE PROJECTOR ON STANDBY OR TWICE TO TURN IT OFF IN BETWEEN USES TO SAVE THE BULB